



**OTR**  
Radial Tires

EARTHMAX SR 22	EARTHMAX SR 31	EARTHMAX SR 35	EARTHMAX SR 41	EARTHMAX SR 30	EARTHMAX SR 23	EARTHMAX SR 49	EARTHMAX SR 49 M	EARTHMAX SR 43	EARTHMAX SR 50	EARTHMAX SR 51	EARTHMAX SR 53	EARTHMAX SR 55

РОССИЯ И СНГ  
VOLVO



in f t v i  
[bkt-tires.ru](http://bkt-tires.ru)  
[bkt-tires.by](http://bkt-tires.by)  
[bkt-tires.kz](http://bkt-tires.kz)

<b>L60F</b>	17.5R25 20.5R25	20.5R25			17.5R25 20.5R25					17.5R25 20.5R25	17.5R25 20.5R25	
<b>L60GZ</b>	20.5R25				20.5R25					20.5R25	20.5R25	
<b>L70F</b>	17.5R25 20.5R25	20.5R25			17.5R25 20.5R25					17.5R25 20.5R25	17.5R25 20.5R25	
<b>L90F</b>	20.5R25				20.5R25					20.5R25	20.5R25	
<b>L90GZ</b>	20.5R25				20.5R25					20.5R25	20.5R25	
<b>L110F</b>	23.5R25		750/65R25	23.5R25						23.5R25	23.5R25	
<b>L120F</b>	23.5R25		750/65R25	23.5R25						23.5R25	23.5R25	
<b>L150H</b>		26.5R25		26.5R25			26.5R25		26.5R25		26.5R25	26.5R25 **
<b>L180H</b>		26.5R25		26.5R25			26.5R25 **		26.5R25 **		26.5R25 **	26.5R25 **
<b>L220H</b>		29.5R25		29.5R25 875/65R29	29.5R25		29.5R25		29.5R25		29.5R25	29.5R25 **
<b>L260H</b>		29.5R25 **	875/65R29	875/65R29			29.5R25 **		29.5R25 **		29.5R25 **	29.5R25 **
<b>L350H</b>							35/65R33 **				35/65R33 **	















**OTR**  
Radial Tires

РОССИЯ И СНГ  
VOLVO



bkt-tires.ru  
bkt-tires.by  
bkt-tires.kz

## Рекомендации давления BKT для стандартных условий (бар)

	17.5R25		20.5R25		23.5R25		26.5R25		750/65R25 *	29.5R25		875/65R29 *	35/65R33 **	
	*	**	*	**	*	**	*	**		*	**			
<b>L60F</b> 	П 5.00 З 4.00	П 6.50 З 5.25	П 5.00 З 4.00	П 6.50 З 5.25										
<b>L60GZ</b> 			П 5.00 З 4.00	П 6.50 З 5.25										
<b>L70F</b> 	П 5.00 З 4.00	П 6.50 З 5.25	П 5.00 З 4.00	П 6.50 З 5.25										
<b>L90F</b> 			П 5.00 З 4.00	П 6.50 З 5.25										
<b>L90GZ</b> 			П 5.00 З 4.00	П 6.50 З 5.25										
<b>L110F</b> 					П 5.00 З 4.00	П 6.50 З 5.25			П 4.75 З 4.00					
<b>L120F</b> 					П 5.00 З 4.00	П 6.50 З 5.25			П 4.75 З 4.00					
<b>L150H</b> 							П 5.00 З 4.00	П 6.50 З 5.25						
<b>L180H</b> 									П 6.50 З 5.25					
<b>L220H</b> 											П 5.00 З 4.00	П 6.50 З 5.25	П 4.75 З 4.00	
<b>L260H</b> 													П 6.50 З 5.25	П 4.75 З 4.00
<b>L350H</b> 													П 6.50 З 5.25	

ПРИМЕЧАНИЕ: ПОЖАЛУЙСТА, ОБРАЩАЙТЕСЬ К ВАШЕМУ ДИЛЕРУ BKT, ЧТОБЫ УЗНАТЬ ДАВЛЕНИЕ ДЛЯ СПЕЦИФИЧЕСКИХ УСЛОВИЙ ЭКСПЛУАТАЦИИ